




# TomTom XXL 540 Screen Replacement

This will walk you through repairing a screen

Written By: Mike Sollars





## TOOLS:


- [T5 Torx Screwdriver](#) (1)
- [Tweezers](#) (1)



## PARTS:

- [TomTom XXL Replacement 5" LCD Touchscreen & Digitizer](#) (1)

## Step 1 — Screen



- Peel back the sticker, using the tweezers on the bottom of the device to reveal the two screws.


## Step 2



- Unscrew the two T5 screws using the T5 Torx Screwdriver.




### Step 3




- Insert the flat head screwdriver into the edge of the device. Using it as a lever, carefully pry the face-plate up.

### Step 4




- Carefully grab the ribbon cable with two fingers and pull the yellow ribbon cable upwards away from the motherboard.

## Step 5




- Remove the screen from of the face-plate.

## Step 6



- Insert the new screen into the face-plate.

## Step 7



- Reattach the yellow ribbon cable to the motherboard.

## Step 8



- Using two hands, hold both ends of the device and snap the two plates together.



## Step 9



- Re-insert the two T5 screws and tighten.

## Step 10



- Re-apply the label edges back down to cover the screws.

To reassemble your device, follow these instructions in reverse order.